

Vest Sizing Guide

Phoenix #2014 Finalist
 Phoenix #2020 Pro-Max
 Phoenix #1225 Pro-Max 1000

Fitting Instructions:

This vest requires measurements of the chest, waist and spine. Remember, the vest is designed to be adjustable at the shoulder as well as the chest and waist. Reference the size chart to select the most appropriate size for your measurements

NOTE: Bull riders should select a Tall size which will provide extended abdominal coverage.


Chest - Measure at the widest point, to a snug fit. See diagram A.

Waist - Measure at the natural waist. See diagram A.

Spine - Measure from the small bump at the back of the neck down to just below the waist. This measurement is best achieved while seated in a chair or saddle. Due to the adjustability of the shoulders, the vest can be shortened or lengthened. A size range rather than one single spine measurement represents this. See diagram B.

Some custom sizes are available at an additional cost. Please allow an additional 4-6 weeks for delivery.

If you need assistance with size selection, contact your local dealer or Phoenix Performance.



Model 2014 – “The Finalist” Model 2020 – “The Pro-Max” Model 1225 – “The Pro-Max 1000”						
Chest		Waist		Spine		Size
IN	CM	IN	CM	IN	CM	
34-38	85-95	28-32	70-80	19-21	48-53	S
38-42	95-105	32-36	80-90	19-21	48-53	M
42-46	105-115	36-40	90-100	19-21	48-53	L
34-38	85-95	28-32	70-80	20-22	50.5-55.5	TS
38-42	95-105	32-36	80-90	21-23	53-58	TM
42-46	105-115	36-40	90-100	21-23	53-58	TL